

Jumper Options

Jumper	Position	Usage
JP1	2-3	Ethernet Config for Axis