

Jumper Options

Jumper	Position	Usage
JP1	1-2	3.3V
JP2	1-2	3.3V
JP3	1-2	I2C3
JP4	1-2	I2C3
JP5	1-2	On-Board CAN
JP6	1-2	On-Board CAN
JP7	1-2	Default GPI/O
JP8	1-2	Default GPI/O
JP11	1-2	I2C3
JP13	1-2	I2C3
JP12	1-2	Enable Power Output
JP14	1-2	Enable Power Output